3110764
Wood Pin Game

Parts List

A.	Game Assembly	1 pc
B.	Game Balls	10 pcs
C.	Baffle Plate	1 pc

* Please make sure that you have all the parts indicated above before you begin assembly of this item.
* This item should be assembled on a soft surface to prevent scratching the finish during assembly.

Assembly Instruction

1. **Attach Baffle Plate (C)** Insert one end of the Baffle Plate (C) into pre-grooved hole in the left side panel of Game Assembly (A). Press the Baffle Plate (C) down into the pre-grooved hole on the right side panel of Game Assembly (A). See illustration.
2. Remove Baffle Plate (C) to return Game Balls (B) to the launching place to play game again. See illustration.
3. Store Game Balls (B) in the small drawer on the back of Game Assembly (A) when game is over.